

Received Event (Event Succeeded)

Date: 7/23/99
 Pages: 15
 Sender: 914 945 4073

Time: 1:14 PM
 Duration: 5 min 4 sec
 Fax Number:

JUL 23 '99 13:31 FR OO-IBM YORKTOWN

914 945 4073 TO 917033053599

P.02/15

After page 22, line 12, add:

Table 1

Emeraldine Base Doped with Compho-sulfonic Acid or Aciamidopropene sulfonic acid

<u>Solvent</u>	<u>Concentration</u>	<u>Conductivity</u>
Trifluoroacetic acid	1%	75 s/cm
	2%	> 100 s/cm
Hexafluoroisopropanol	1%	75 s/cm
	2%	100 s/cm
	3%	> 100 s/cm
Tetrafluoroisopropanol 50	1%	100 s/cm
Hexafluorophentolpropanol 50	2%	200 s/cm
Hexafluoroisopropanol (HFIP)	3%	100 s/cm
Tetrafluoropropanol (TFP)		
25175		
HFIP/TFP 50/50 50/50	3%	200 s/cm
HFIP/TFP 75/25 75/25	3%	170 s/cm
HFIP/TFP 63/37 63/37	3%	130 s/cm
Perfluoro butyl alcohol	3%	120 s/cm
2,3,4,6 Tetrafluorophenol	3%	200 s/cm
Tetrafluoropropanol	3%	40 s/cm
Hexafluorophentolpropanol / Clcolhexanone	3%	75 s/cm
Hexafluorophentolpropanol / anisole	3%	75 s/cm
4-(Trifluoromethyl) Bentl alcohol	3%	50 s/cm
2,4 Difluorobentyl alcohol	3%	50 s/cm
4-Flourobentyl alcohol	3%	75 s/cm
Hexafluoropropenol / Bentyl alcohol	3%	75 s/cm
Hexafluoropropenol / Bentyl alcohol	3%	75 s/cm
HFIP / pentafluoropropenol 50150	3%	140 s/cm